WEHRLEY Pin 30: Pin 87: Pin 85: 86 85 Pin 86: Pin +APC: Klemme LED: output min. 16mm² min. 16mm² Battery 1 Battery 2 (Starter)

Wiring diagram 68 201 001

Battery / starter battery which is charged by the alternator

Additional Battery

Ground

Measurement input, connect the battery here which should be

monitored (starting battery)

(optional) Input for a manual connection of the 2 batteries. If there

is a input of 12V (e.g. with a simple switch) the batteries are

connected (independently of the voltages)

(optional) control LED output if the relay is switched on, positive